

1/14

FIG. 1







FIG. 2






4/14

FIG. 4




5/14

FIG. 5




6/14

FIG. 6




7/14

FIG. 7




8/14

FIG. 8




9/14

FIG. 9




10/14

FIG. 10



11/14

FIG. 11



12/14

FIG. 12A





FIG. 12B



13/14

FIG. 13A

ROTATIONAL POSITION	HALL ELEMENT			CODE VALUE (HEXADECIMAL)
	H1	H2	H3	
PS1	1	0	1	5
PS2	0	0	1	1
PS3	0	1	1	3
PS4	0	1	0	2
PS5	1	1	0	6
PS6	1	0	0	4

FIG. 13B

ROTATIONAL POSITION	HALL ELEMENT			CODE VALUE (HEXADECIMAL)
	H1	H2	H3	
PS1	1	0	1	5
PS2	1*	0	1	5
PS3	1*	1	1	7
PS4	1*	1	0	6
PS5	1	1	0	6
PS6	1	0	0	4

* : ERROR OUTPUT

14/14

FIG. 14

